For Low Pressure (Air)

Hi Cupla for Connection to Braided Hoses Nut Cupla Nut Cupla 200 Rotary Nut Cupla For connection to urethane hose



No hose clamp required! Fitted with hose guard nut to prevent possible kinking. Hi Cupla for connection to braided hoses is now available.

- Nut types are available in Hi Cupla Series and Hi Cupla 200 Series. Hose guard nut type available to prevent hose kinking.
- To mount on hose, simply slide it over the nipple and tighten the nut.
- The design to tighten outside of hose reduces hose slip away or fluid leaks.
- Also available are Rotary Nut Cupla equipped with ball bearing swivel mechanism to prevent and relieve tension on operator's hands.



Specifications (Nut Cup	ola / Nut Cupla	a 200 / Rotary	Nut Cupla)					
Body material		Steel (Chrome-plated)							
		For ø5 mm × ø8 mm, ø6 mm × ø9 mm hose							
Urethane hose size		For ø6.5 mm × ø10 mm, ø8 mm × ø12 mm hose							
		For ø8.5 mm × ø12.5 mm, ø11 mm × ø16 mm hose							
	MPa	1.5							
Working pressure	kgf/cm ²	15							
	bar	15							
	PSI	218							
Seal material Working temperature range		Seal material	Mark	Working temperature range	Remarks				
		Nitrile rubber	NBR (SG)	-20°C to +60°C	Standard materia				
Specifications (Hi Cupl	a for Connect	ion to Braideo	l Hoses)					
Body material		Steel (Chro	me-plated)	Brass					
Braided hose size		For ø9 mm × ø15 mm hose							
Working pressure	MPa	1.	5	1.0					
	kgf/cm ²	1	5	10					
	bar	1	5	10					
	PSI	2-	18	145					
Seal material		Seal material	Mark	Working temperature range	Remarks				
Working temperature range		Nitrile rubber	litrile rubber NBR (SG) -20°C to +80°C		Standard material				
Working pressure and tempera	ature range o	f PN/SN type for braide	d hoses depends upon	the specification of the t	praided hose to be used				

Tightening Torque Range Nm {kgf•cm}							
Model	SN, PN, SNR Type	65SNG, PNG, SNRG Type	85SNG, PNG, SNRG Type				
Torque	9 to 11 {92 to 112}	5 to 6 {51 to 61}	7 to 8 {71 to 82}				
To mount on braided hose or urethane hose slide it over to the hose barb and tighten the nut until it is flush against the hose barb hase							

To mount on braided hose or urethane hose, slide it over to the hose barb and tighten the nut until it is flush against the hose barb base. It is recommended that grease is applied to the inside of the nut (threaded part and hose contact part) for easy tightening.

Flow Direction



Interchangeability

Interchangeable with Hi Cupla Models 10, 17, 20, 30 and 40. Interchangeable with each corresponding Hi Cupla Series models.


Min. Cross-Sectional Area (mm ²)												
Plug Socket	17PH	20PH	30PH	40PH	10PM	20PM	30PM	40PM	20PF	30PF	40PF	90PN-BH
200-50SN	16	16	16	16	13	16	16	16	16	16	16	16
200-60SN	16	20	22	22	13	22	22	22	22	22	22	22
200-65SN	16	20	22	22	13	22	22	22	22	22	22	22
200-80SN	16	20	41	41	13	41	41	41	41	41	41	41
200-85SN	16	20	41	41	13	41	41	41	41	41	41	41
200-110SN	16	20	41	41	13	41	41	41	41	41	41	41
200-50SNG	16	16	16	16	13	16	16	16	16	16	16	16
200-65SNG	16	20	22	22	13	22	22	22	22	22	22	22
200-85SNG	16	20	40	41	13	41	41	41	41	41	41	41
90SN-BH	16	20	33	33	13	33	33	33	33	33	33	33

Suitability for Vacuum


Not suitable for vacuum application in either connected or disconnected condition.

Pressure - Flow Characteristics

[Test conditions] •Fluid : Air •Temperature : Room temperature



Hi Cupla for Connection to Braided Hoses / Nut Cupla / Nut Cupla 200 / Rotary Nut Cupla Nut Cupla 200) WAF stands for width across flats.



Before use, please be sure to read "Safety Guide" described at the end of this book and "Instruction Sheet" that comes with the products